

Tea Strainer Set

取扱説明書

ご使用の際には取扱説明書をよく読んでからご使用ください。
この取扱説明書は必ず保管してください。

△ ご使用上の注意

- ・ご使用になる前に不具合(変形・破損等)がないことを確認してください。
- ・無理な力で曲げたり、叩いたりしないでください。
- ・熱い飲み物を入れた際にはグラス急須に直接触れないようにお気をつけください。
- ・使用後はよく洗って乾燥させて保管してください。
- ・品質には万全を期しておりますが、万一商品に不具合があった場合、またはお気づきの点がございましたらご連絡ください。

生産国 ワイヤーフレーム 茶こし・WIRE FLAME(ワイヤー製取手): 日本製 グラス急須・フタ: インド製

● 茶こし

[材質/ステンレス鋼(18-8),ゴールドメッキ]

- ・食器洗浄機でご使用にならないでください。
- ・次亜塩素酸ナトリウムはご使用にならないでください。

● グラス急須・フタ

[材質/グラス急須:ホウケイ酸ガラス(最高耐熱温度350°C・耐熱温度差150°C) フタ:ソーダガラス ※耐熱ガラスではありません]

- ・耐熱温度差(150°C)以上の急激な温度変化とならないようご注意ください。
- ・加熱した製品を濡らした布や冷えた作業台の上に置かないでください。
- ・調理時は外滴をぬぐい、差し水の際は冷水の使用を避けてください。
- ・空焚きは絶対に避けてください。
- ・加熱時は突沸に注意し、顔などを近づけないでください。
- ・加熱時は器具の中心に置き、弱火で使用してください。
- ・洗浄の際、金属タワシやクレンザーなどの表面を傷つける恐れのある用具は避けてください。
- ・フタはソーダガラス製で耐熱仕様ではございません。

ワイヤーフレーム

● WIRE FLAME (ワイヤー製取手)

[材質/ステンレス鋼(18-8)]

- ・食器洗浄機でお使いいただけます。
- ・サイズに若干の個体差がある場合がございます。グラス急須に対して当商品が小さい場合は広げるように、大きい場合は狭めるようにご調整の上ご使用ください。

Tea Strainer Set

Instruction Manual

Please read and review all operating instructions carefully and use, and keep this manual in a safe.

⚠ Precautions

- Before using, check the product to ensure there is nothing wrong with it.
- Do not subject the product to any blunt force. The product can be easily deformed.
- Please be caution not to touch glass directly when hot drinks in it.
- After use, wash and dry well.
- If this product appears to be defective in any way, do not use the product and contact the following number.

Country of Origin

Tea Strainer · WIRE FLAME (wire handle) : Made in Japan
Glass kyu-su · Lid : Made in India

● Tea Strainer

[Material / 18-8 stainless steel, gold plating]

- Do not wash in dishwasher machine.
- Do not use sodium hypochlorite.

● Glass kyu-su · Lid

[Material / Glass kyu-su : borosilicate glass (upper temperature limit 350°C · temperature change limit 150°C)
Lid : soda lime glass *not heat resistant]

- Do not heat or cool a glass over temperature change limit (150°C).
- Do not place heated a glass on a cold working table or wet cloth.
- Please wipe beading and do not add cold water when a glass is heated.
- Do not heat a glass with no water in it.
- Please be caution with bumping in heating, avoid your face to be closer.
- Please place a glass on center of equipment in heating, use it at low heat.
- When you wash a glass, avoid to use tools that have risk of scratch surface of it, for example wire wool or cleanser.
- Lid is made of soda lime glass, it's not heat resistant.

● WIRE FLAME (wire handle)

[Material / 18-8 stainless steel]

- Available to using dishwasher.
- There will be some individual differences. Please expand handle width in case of WIRE FLAME is smaller than glass diameter, or otherwise narrow in case of larger than it.